

Wonder Knitter™

NEW

WONDER KNITTER™



Beading

Fashion goods



Knitted toy

Art No. 3101 WONDER KNITTER™	
Description	1 set, card
Packing	6 cardboard
P. Size	5" x 8 3/4" x 2 1/4"
Retail Price	US\$ 8.50

One-touch disk replacement!

Knit narrow braided cord with "three-pin disk", and wide cord with "six-pin disk", respectively. Two width types of braided cord can be knitted by switching disks.



You can make braided cord quick and easy.

The secret of quick and easy lies in rotatable disk.

The thread hooks on preferable position one by one by rotating the disk.

No adjustment of thread position and tension is needed. Very simple.



How to use Wonder Knitter

1. Pick up the lower thread.
2. Pull it up and hook on the pin.
3. Rotate the disk and go to the next stop.

CLOVER NEEDLECRAFT, INC.

1007 E. Dominguez St., Suite "L", Carson, CA 90746
 Tel: (310) 516-1800
 Fax: (310) 516-1828
 E-mail: cn@mail.cloverusa.com
 URL: <http://www.clover-usa.com>

Clover



DESIGN SCARF WITH CLOVER WONDER KNITTER

The Craft Needlecraft (Australia)
 PO Box 226
 Maroubra NSW 2035
 Australia
 Tel: +61 (0)2 9392 721
 Fax: +61 (0)2 9392 754
 Email: sales@craftmailbox.com.au




Clover



DESIGN BEADED ACCESSORIES USING CLOVER WONDER KNITTER



Beaded Accessories



Tools

- Wonder Knitter™
- Needle-nose pliers
- Scotch tape


Materials for Shimmering Bracelet (Pink shade)

Material	Size	Color	Quantity
Cut beads	5 mm	Light pink	12-16 pieces
(Diamond shaped beads)	5 mm	Light blue	6-8 pieces
	3 mm	Pink	7-9 pieces
Kidney shaped beads		Clear	5-7 pieces
Small round beads		Clear	6-8 pieces
Extra small beads		Clear	19-25 pieces
Fishing line	0.29 mm		Approx. 4 yards
Ball clasp			2 pieces
Clasp Opener			1 set
Clasp			2 pieces

How to make a shimmering bracelet (Pink shade)

- (1) Put a piece of scotch tape at the end of the fishing line, and string through beads in the order shown in the diagram to the left.
- (2) Set up the fishing line with beads strung on the Wonder Knitter™ "three-pin disc", and knit 10 pin stitches (※) with only the fishing line until stitches are stabilized.
- (3) Remove the fishing line from the guide, and place 2 beads between the pins on the disc. Reset the fishing line, knit one set of stitches, remove the fishing line again, and place two beads between the pins as before.
- (4) Set the fishing line on the guide again, and knit three sets with the fishing line alone.
- (5) Repeat (3) and (4) until all beads are knitted into a spiral shape, and knit 10 sets with the fishing line alone.
- (6) Close the stitches, and attach end pieces such as ball clasp and the clasp opener to finish.

※Knitting one pin counts as "one stitch". When using "three-pin disc" knitting one turn on the disc will be knitting "three stitches".



For further details on using the Wonder Knitter, please refer to the instructional manual.

Yarn-knitted scarf

Tools

- Wonder Knitter™
- Sewing needle

Materials

Yarn-knitted scarf
(5-1/2 in. in width, 45-1/4 in. in length)
Velvet cloth
(7-3/4 in. in width, 46-3/4 in. in length)
One ball of silk yarn, medium thickness
99 plastic beads
(5-6 mm diameter)
Hand sewing thread (for sewing and attaching velvet cloth and knitted strings)

Procedure

1. Knit strings using the Wonder Knitter™ (use "three-pin disc").
* For knitting instructions, refer to the user's guide accompanying the Wonder Knitter™
(1) String 9 beads onto the silk yarn.
(2) Use the silk yarn prepared in step (1) above and put it together with another strand of yarn without beads strung on it; use these to knit 11 integrated strands, each approximately 19-3/4 in. in length.
* For knitting instructions, refer to the section entitled "Adding beads on yarn" in "How to Use Wonder Knitter"
2. Sew the velvet cloth onto the scarf.
3. Attach knitted strings prepared in item 1 on the velvet cloth side of the scarf.

